



**GASTROPARTS**

# Elettrobar

**[EN]** Cooking

**[DE]** Kochtechnik

**[ES]** Cocción

**[FR]** Cuisson

**[IT]** Cottura

**[PL]** Obróbka termiczna

**[RU]** Термическая обработка

✉ [gastroparts@gastroparts.com](mailto:gastroparts@gastroparts.com)


☎ tel. +48 56 657 00 66

📘 [fb.com/gastroparts.global](https://fb.com/gastroparts.global)


**GASTROPARTS.COM**




## Toasters




Item	Order	Description	Model	OEM
1	416493	quartz tube	406	484001
2	416494	500W/115V		233001
3	416495	1000W/230V	412	923003



Item	Order	Description	Model	OEM
1	359041	signal lamp		216012
2	359042	signal lamp	433, 434, 436, 437,	216016
3	390139	thermostat	438, 439, G33, G34, G37, G38, G39	921014 921046
4	110285	knob		921039




Item	Order	Description	Model	OEM
1	345547	switch	406	213001
2	110339	knob		999045
3	345579	switch	412	923011
4	110326	knob		999081




Item	Order	Description	Model	OEM
1	350028	timer		923012 222001
2	110004	knob	406, 412	999044
3	690010	pliers		433004

## Contact grills




Item	Order	Description	Model	OEM
1	416496	700W/230V (upper)	433, 434, 436, 437,	921017
1	416497	1000W/230V (lower)	438, 439, G33, G34, G37, G38, G39	921008
2	690511	spring		921005


## Fryers




Item	Order	Description	Model	OEM
1	416499	3300W/230V	FRI16	230069
2	416504	3300W/230V	FRI9	230070
3	416505	4950W/400V	FRT9	230068



Item	Order	Description	Model	OEM
1	416506	6600W/400V	FRI12, FRI15m	230072
2	416507	8250W/400V	ME15, ME30	230073
3	416508	10950W/400V	ME20, ME40	230074



Item	Order	Description	Model	OEM
1	375507	safety thermostat	universal	236034 236045
2	380238	protection	FRI6/9/12/15m	229032
3	380423	protection	ME15/20/30/40	229016
4	359041	signal lamp		216012



Item	Order	Description	Model	OEM
1	345547	switch	ME15, ME20,	213001
2	110339	knob	ME30, ME40	447059
3	375618	thermostat	universal	236033 236044
4	110354	knob		921002 447147




Item	Order	Description	Model	OEM
1	375200	safety thermostat	MG_	236015
2	540699	drain tap	FRI	720008
3	540646	drain tap	ME_, MG_	720010



Item	Order	Description	Model	OEM
1	550061	sensor clamp	FRI6/9 (230V)	033286
2	550062	sensor clamp	FRI6-15 (400V)	033287
3	n. l. a.	sensor clamp	ME_	033278




Item	Order	Description	Model	OEM
1	970294	basket	FRI6	706088
2	970295	basket	FRI9	706089
3	970296	basket	FRI12, FRI15m	706090




Item	Order	Description	Model	OEM
1	101131	Minisit		611001
2	101136	cover with Piezzo	MG15, MG20,	611002
3	110068	knob	MG30, MG40	447060
4	101265	interrupter		468068



Item	Order	Description	Model	OEM
1	970297	basket 1/2	ME15, ME30,	706097
2	970298	basket 1/1	MG15, MG30	706092



Item	Order	Description	Model	OEM
1	100192	pilot burner		611003
2	102094	thermocouple	MG15, MG20,	611005
3	100701	electrode	MG30, MG40	611006
4	100026	ignition cable		611007



Item	Order	Description	Model	OEM
1	970299	basket 1/2	ME20, ME40,	706096
2	970300	basket 1/1	MG20, MG40	706093

**GASTROPARTS.COM**



© 2020 Gastroparts Sp. J. All rights reserved.