



GASTROPARTS

Star Indesit

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

✉ gastroparts@gastroparts.com

☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global


GASTROPARTS.COM




Open tops (gas)



Item	Order	Description	Model	OEM
1	105904	burner cover, 89mm		10013105619
2	105902	burner ring		10013111230
3	105898	burner base		10013117943
4	105899	jet holder		10013002540




Item	Order	Description	Model	OEM
1	210229	top grate/side		1009000311, 1360011500
2	210230	top grate/in centre		1009001720, 1360011610



Item	Order	Description	Model	OEM
1	105903	burner cover, 69mm		10013105629
2	105901	burner ring		10013111240
3	105900	burner base		10013117952
4	105899	jet holder		10013002540

Ovens (electric)




Item	Order	Description	Model	OEM
1	346432	switch		10013101570
2	346433	cap		10013099700
3	359718	bulb + housing		10013177630




Item	Order	Description	Model	OEM
1	106025	gas tap		10013161470
2	111884	knob		10013144970
3	102056	thermocouple		10013039501




Item	Order	Description	Model	OEM
1	359701	bulb holder		-
2	359610	bulb, 15W		-
3	359709	lens		-




Item	Order	Description	Model	OEM
1	346002	ignition switches		10013101580
2	346433	cap		10013099700
3	101037	ignition unit		10013234490, 10001493104
4	102375	electrode		10013116030
5	532508	O-ring		10013151140



Item	Order	Description	Model	OEM
1	375723	thermostat		10013023740, 16001142401
2	300114	switch		10013000860
3	111884	knob		10013144970
4	359141	signal lamp		10013000611, 16001518000



Item	Order	Description	Model	OEM
1	415774	heating element/upper		10013150420, 16002032700
2	415775	heating element/lower		10013150430



Item	Order	Description	Model	OEM
1	690037	hinge		10013160490
2	700498	counter part		10013160480
3	900511	door seal		10013150180, 1440016280

GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.