



GASTROPARTS

Ubert

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

✉ gastroparts@gastroparts.com


☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global

GASTROPARTS.COM




Open tops (electric)




| Item | Order | Description | Model | OEM |
|------|--------|-------------------|--------------------|--------|
| 1 | 490018 | 2000W/230V | | 343203 |
| 2 | 300025 | 7-position switch | MS0180E MS0182E | |
| 3 | 110191 | knob | | |
| 4 | 110522 | symbol | | |

Fry tops/sausage roasters (electrical)



| Item | Order | Description | Model | OEM |
|------|--------|-------------|--|--------|
| 1 | 415567 | 2200W/240V | MS0160E, MS0162E, MS0164E, MS0170E, MS0172E, MS0174E | 343126 |
| 2 | 416964 | 2200W/240V | | |




| Item | Order | Description | Model | OEM |
|------|--------|-------------|--|--------|
| 1 | 375012 | thermostat | MS0160E, MS0162E, MS0164E, MS0170E, MS0172E, MS0174E | 342229 |
| 2 | 110191 | knob | | - |
| 3 | 110520 | symbol | | - |



| Item | Order | Description | Model | OEM |
|------|--------|------------------|--|--------|
| 1 | 380015 | energy regulator | MS0160E, MS0162E, MS0164E, MS0170E, MS0172E, MS0174E | 341141 |
| 2 | 110191 | knob | | |
| 3 | 111743 | symbol | | |

Chargrills (electric)




| Item | Order | Description | Model | OEM |
|------|--------|-------------|--------------------|--------|
| 1 | 415564 | 550W/230V | MS0140E | |
| 2 | 416913 | 5200W/230V | MS0142E MS0144E | 343131 |




| Item | Order | Description | Model | OEM |
|------|--------|------------------|-------------------------------|--------|
| 1 | 380015 | energy regulator | MS0140E MS0142E MS0144E | 341141 |
| 2 | 110191 | knob | | |
| 3 | 111743 | symbol | | |

Fry tops/sausage roasters (electrical)




| Item | Order | Description | Model | OEM |
|------|--------|------------------|--------------------|--------|
| 1 | 415561 | 2000W/230V | | 343103 |
| 2 | 375143 | thermostat 110 C | MS0130E MS0132E | |
| 2 | 375019 | thermostat 85 C | MS0133E MS0135E | 342217 |
| 3 | 110191 | knob | | - |
| 4 | 110547 | symbol | | - |
| 5 | 111744 | symbol | | |



| Item | Order | Description | Model | OEM |
|------|--------|-------------|---------|--------|
| 1 | 415561 | 2000W/230V | | 343103 |
| 2 | 375019 | thermostat | MS0112E | 342217 |
| 3 | 110191 | knob | | - |
| 4 | 111744 | symbol | | - |


Universal parts



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------|--------------------|--------|
| 1 | 415566 | 2000W/230V | | 343104 |
| 2 | 390015 | thermostat with limiter | MS0100E MS0101E | 342213 |
| 3 | 375016 | safety thermostat | MS0102E | 342212 |



| Item | Order | Description | Model | OEM |
|------|--------|----------------------|----------------------------|--------|
| 1 | 359130 | signal element | | 340732 |
| 2 | 359127 | insert lamp holder | universal modul devices | |
| 3 | 359132 | signal element/green | | 340733 |
| 4 | 359126 | insert lamp holder | | |



| Item | Order | Description | Model | OEM |
|------|--------|-------------|---------|--------|
| 1 | 375022 | thermostat | MS0100E | 342206 |
| 2 | 110191 | knob | MS0101E | - |
| 3 | 110518 | symbol | MS0102E | - |



| Item | Order | Description | Model | OEM |
|------|--------|----------------------|------------------------------|-----|
| 1 | 359110 | signal element | | - |
| 2 | 359804 | lens | universal install devices | |
| 3 | 359109 | signal element/green | | - |
| 4 | 359803 | lens | | |



| Pos. | Order | Description | Model | OEM |
|------|--------|-------------|-------------------------------|-----|
| 1 | 970384 | basket | MS0100E MS0101E MS0102E | FK3 |

GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.