



GASTROPARTS

Universo

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

✉ gastroparts@gastroparts.com

☎ tel. +48 56 657 00 66

📘 fb.com/gastroparts.global


GASTROPARTS.COM



Lava rock grill



Item	Order	Description	Model	OEM
1	105421	burner	PLX47, PLX80	PLX20002
2	211012	lava rock grid		PLX20029



Item	Order	Description	Model	OEM
1	105422	burner	PLV60	PLX20003
2	211013	lava rock grid		PLX20030




Item	Order	Description	Model	OEM
1	101087	gas tap	PLX47, PLX60, PLX80	PLX20009
2	110080	knob		PLX20010
3	110082	symbol ring		PLX20004
4	100046	pilot burner		




Item	Order	Description	Model	OEM
1	102041	thermocouple	PLX47, PLX60, PLX80	PLX20039
2	100708	electrode		PLX20034
3	100018	ignition cable		PLX20008
4	100003	piezoelectric igniter		PLX20001

Chicken grill




Item	Order	Description	Model	OEM
1	105428	burner	GS246, GS312, GS416	GS20032
2	105429	burner	GS366	GSP080




Item	Order	Description	Model	OEM
1	100079	pilot burner	GS246, GS312, GS366, GS416	GS20030
2	102041	thermocouple		PLX20039
3	100701	electrode		GS20038
4	100018	ignition cable		PLX20008



Item	Order	Description	Model	OEM
1	100003	piezoelectric igniter	GS246, GS312, GS366, GS416	PLX20001
2	101086	gas tap		GSP041
3	110080	knob		A0377
4	110082	symbol		




Item	Order	Description	Model	OEM
1	416016	1700W/230V	GE312	A0344
2	416017	2400W/230V	GE246	A0352
3	416025	3200W/230V	GE366	A0351
4	416026	2300W/230V	GE416	A0353




Item	Order	Description	Model	OEM
1	345424	step switch	GE246	A0367
2	345576	light switch	universal	GES20017
3	359259	lamp, complete		A0339



Item	Order	Description	Model	OEM
1	345981	switch (motor)		GES20018
2	345648	switch (heating)	GE312, GS312	GES20016
3	345649	push button/start		GES20019



Item	Order	Description	Model	OEM
1	345671	push button		A0341
2	345672	push button, stop	GE246, GS246,	A0341
3	345673	selector switch, I-0-II	GE366, GS366,	A0358B
3	345674	selector switch, 0-I	GE416, GS416	A0358A
4	345669	contactor block		A0330



Item	Order	Description	Model	OEM
1	380134	relay		GES20022
2	500499	motor	GE312, GS312	GES20026
3	690508	skewer inlet		GES20032

GASTROPARTS.COM



© 2020 Gastroparts Sp. J. All rights reserved.