




BTESBM
Electric Bain-Marie



Spare Parts

Key N°	Part N°	Description
1	RTBF900454	CLAMP
2	RTCP700003	WATER TAP
3	RTCU700324	FOOT
4	RTCU900012	BICONE Ø10
5	RTCU900013	NUT Ø10
6	RTCU900121	ELBOW
7	RTCU900415	FEEDING CABLE
8	160021	RIGHT SIDE
9	160022	INOX BACK PANEL
10	160025	BOTTOM TOP
11	160028	BRACKET TO FIX CONTROL PANEL
12	160085	(R) RESISTANCE ELET. 2,5KW
13	163270	TANK
14	160213	CREW ELEMENT
15	160214	WATER DISCHARGE TAP
16	160222	WATER TAP FEEDING PIPE
17	160223	WATER FEEDING PIPE
18	160224	WATER DISTRIBUTOR
19	160226	WATER DISCHARGE PIPE
20	160230	SUPPORT PLAN FOR ELEMENT
21	163222	CHIMNEY GRILL
22	160319	LEFT SIDE
23	160341	TAP EXTENSION
24	160353	LEFT WATER TAP CREW
25	160354	RIGHT WATER TAP CREW
26	160380	ROD GUIDE
27	160398	TERMINAL BOARD BAR
28	161227+163083	(R) THERMOSTAT KNOB
29	160470	DRAIN KNOB
30	163114+163079	(R) TAP KNOB
31	160506	(R) ORANGE WARNING LIGHT
32	160505	(R) GREEN WARNING LIGHT
33	RTCU900110	(R) COMMUTATOR
34	RTBF800152	(R) THERMOSTAT
35	RTBF900037	LOW FLASK
36	163186	DASH BOARD

(R) = - Recommended spare parts