




OVENS
HGFO7
HEFO7
HEFOV7




Spare Parts






Key No	Part No	Description
1	PACU700569	OVEN DOOR
2	PACU700447	OVEN DOOR HANDLE
3	RTCU700291	HANDLE
4	RTCU900027	OVEN DOOR LEFT HINGE
5	RTCU900026	OVEN DOOR RIGHT HINGE
6	RTCU900004	HINGE SUPPORT
8	RTCU800097	OVEN DOOR GASKET
9	RTCU700342	OVEN LATERAL GRATE
10	RTCU700341	GRATE
11	RTCU700002	GRATE CONNECTION
12	PACU700587	AIR CONVEYOR
14	RTCU700277	STAINLESS STEEL FOOT
15	PACU700795	RIGHT SIDE
16	PACU700386	
17	PACU700835	COVER
18	PACU700794	STAINLESS STEEL BACK PANEL
19	RTCU700344	THERMOSTAT HANDLE
20	RTCU700289	GAS THERMOSTAT
22	RTCU900061	THERMOCOUPLE CM. 120
23	RTCU700297	NUT FOR PIPE Ø 10
24	RTCU900012	DOUBLE CONE D.10
25	RTCU900018	BICONE FOR PIPE Ø 6
26	RTCU900019	NUT FOR PIPE Ø 6
27	RTCU900013	NUT
29	RTCU700020	PIEZO LIGHTING
30	RTCU700410	LIGHTING CABLE
31	PACU700838	FEEDING PIPE BURNER
32	PACU700839	FEEDING PIPE PILOT
33	RTCU700377	OVEN BURNER
34	RTCP800034	PILOT BODY
35	RTCP800033	SPARK PLUG
36	RTCP800038	THERMOCOUPLE FITTING
37	RTCP800041	INJECTOR PILOT Ø 0,19 FOR LPG
37	RTCP800059	NATURAL GAS INJEC. PILOT Ø 0,27
38	RTCU900337	INJECTOR SUPPORT
40	PACU700801	FEET FIXING CROSSBAR
41	PACU700837	LEFT SIDE



Key No	Part No	Description
1	PACU700569	OVEN DOOR
2	PACU700447	OVEN DOOR HANDLE
3	RTCU700291	HANDLE
4	RTCU900027	OVEN DOOR LEFT HINGE
5	RTCU900026	OVEN DOOR RIGHT HINGE
6	RTCU900004	HINGE SUPPORT
7	PACU700570	OVEN COUNTER DOOR
8	RTCU800097	OVEN DOOR GASKET
9	RTCU700342	OVEN LATERAL GRATE
10	RTCU700341	GRATE
11	RTCU700002	GRATE CONNECTION
12	GACU700211	LEFT SIDE
13	PACU700559	OVEN PLAN
14	RTCU700277	STAINLESS STEEL FOOT
15	PACU700795	RIGHT SIDE
16	PACU700793	OVEN CONTROL PANEL
17	PACU700791	COVER
18	PACU700794	STAINLESS STEEL BACK PANEL
19	PACU700695	TERMINAL BOARD INSPECTION COVER
22	RTCU700437	OVEN KNOB
23	RTCU900290	GREEN WARNING LAMP
25	RTCU700079	OVEN COMMUTATOR
26	RTCU600067	THERMOSTAT
28	RTCU700103	CABLE GUIDE
29	RTBF900045	TERMINAL BLOCK 6 POLES
30	RTCU700282	OVEN GRILL ELEMENT 3,75 KW 240 V
31	RTCU700281	OVEN ELEMENT 2,7 KW 240 V
32	PACU700801	FEET FIXING CROSSBAR



Key No	Part No	Description
1	PACU700569	OVEN DOOR
2	PACU700447	OVEN DOOR HANDLE
3	RTCU700291	HANDLE
4	RTCU900027	OVEN DOOR LEFT HINGE
5	RTCU900026	OVEN DOOR RIGHT HINGE
6	RTCU900004	HINGE SUPPORT
7	PACU700570	OVEN COUNTER DOOR
8	RTCU800097	OVEN DOOR GASKET
9	RTCU700581	OVEN LATERAL GRATE
10	RTFOC00017	OVEN GRATE
11	RTCU700599	DOOR GASKET LOWER
12	GACU700211	LEFT SIDE
13	PACU701154	FAN
14	RTCU700277	STAINLESS STEEL FOOT
15	PACU700795	RIGHT SIDE
16	PACU700793	OVEN CONTROL PANEL
17	PACU700791	COVER
18	PACU700794	STAINLESS STEEL BACK PANEL
19	PACU700695	TERMINAL BOARD INSPECTION COVER
20	PACU700801	FEET FIXING CROSSBAR
21	RTFOC000623	MOTOR + FAN
22	RTCU700453	OVEN KNOB
23	RTCU900290	GREEN WARNING LAMP
24	RTCU900072	YELLOW WARNING LAMP
25	RTCU700454	OVEN COMMUTATOR
26	RTCU700455	OVEN COMMUTATOR
28	RTCU700103	CABLE GUIDE
29	RTBF900045	TERMINAL BLOCK 6 POLES
30	RTCU700650	RESISTANCE



As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.

15.09.2003-Issue-1