




## HGF 66 Fryer



*Spare Parts*





Key No	Part No	Description
1	161492	Control panel ( HOBART PANEL )
2	GACU600011	Tank
3	PACU600040	Rear wall
4	RTCU600081	Hook for tank
5	GACU600009	Chimney
6	PACU600044	Stainless steel back panel
7	PACU600002	Left side Panel
8	PACU600027	Bottom
9	<b>144605-73</b>	<b>Grate</b>
10	<b>A660310</b>	<b>Basket</b>
11	<b>144605-35</b>	<b>Cover</b>
12	PACU600125	Crossbar
13	PACU600056	Flange
14	PACU600429	Lock rod
15	<b>144605-59</b>	<b>Foot</b>
16	144605-51	Water discharge tap
17	<b>RTCU900222</b>	<b>Valve safety knob</b>
18	RTCU700318	Descharge pipe
19	RTCU600422	Tap rod
20	<b>144605-92</b>	<b>Safety valve knob</b>
21	<b>144605-76</b>	<b>Piezo lighting</b>
22	<b>144605-105</b>	<b>Spark plug</b>
23	<b>144605-97</b>	<b>3 ways pilot</b>
24	<b>144605-38</b>	<b>Cable for piezo lighting</b>

Key No	Part No	Description
25	????????????	NO LINK
26	RTCU700141	Bicone + fitting
27	????????????	NO LINK
28	PACU600058	Valve unit support
29	144605-103	Thermocouple
30	RTCU700610	Elbow T 3/8
31	RTCU600082	Hook for tank
32	RTCU600077	Tubo al. Bruciatore DX
33	RTCU700293	Indicator
34	144605-98	Burner
35	144605-109	O-Ring
36	RTCU900220	Pipe coupling valve
37	RTCU900103	Nipples
38	RTCU600027	Collector
39	144605-100	Valve unit ( RTCU600079 Pipe from gas valve to pilot assy )
40	RTBF800020	Handle
41	PACU600129	Squadra porta termostato
42	PACU600003	Right side Panel
43	144605-44	Limit thermostat
44	RTCU600078	Tube
45	RTCU900013	Nut
46	RTCU900012	Bicone ~10
47	144605-58	Injector Support
48	RTCU900005	Support Lock Nut
49	144604-167	ECOMAX - Logo



As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.

12.06.2003-Issue-1