


**HOBART**




***Electric Pasta Cooker***  
**BCEDPC / BMEDPC**



***Spare Parts***





BMEDPC  
BCEDPC

Key N°	Part N°	Description
1	A800001260	BASKET 1/ 3 16X29X21,5
2	RTBF800041	WATER DISTRIBUTOR
3	RTCU800343	GRATE FOR BASKET
4	163221	WORK PLANE GRATE
5	GACU800181	BASKET SUPPORT PANEL
6	163903	BOWL
7	RTCU800342	(R) R. EC45/ 2 3KW
8	RTBF900045	TERMINAL BOARD
9	RTCU700324	FOOT
10T	160433	RIGHT SIDE <b>(BCEDPC)</b>
10	162676	RIGHT SIDE <b>(BMEDPC)</b>
11T	160434	LEFT SIDE <b>(BCEDPC)</b>
11	162677	LEFT SIDE <b>(BMEDPC)</b>
12T	164962	LEFT HINGE <b>(BCEDPC)</b>
12	162198	LEFT HINGE <b>(BMEDPC)</b>
13T	164963	RIGHT HINGE <b>(BCEDPC)</b>
13	162199	RIGHT HINGE <b>(BMEDPC)</b>
14	RTBF800073	WATER DISCHARGE TAP
15	RTCP900036	COMM. CPE
16	RTCP900074	(R) T. L.
17	160505	(R) GREEN WARNING LAMP
18	RTTAV00093	MAGNET
19	RTBF800021	DOOR RUBBER CAP
20T	160096	DOOR <b>(BCEDPC)</b>
20	162196	DOOR <b>(BMEDPC)</b>
21T	160095	COUNTER DOOR <b>(BCEDPC)</b>
21	162197	COUNTER DOOR <b>(BMEDPC)</b>
22T	160270	COVER <b>(BCEDPC)</b>
22	162457	COVER <b>(BMEDPC)</b>
23	160028	BRACKET TO FIX THE CONTROL PANEL
24T	160122	LOWER PLANE <b>(BCEDPC)</b>
24	162727	LOWER PLANE <b>(BMEDPC)</b>
25	163074	COMMUTATOR KNOB
26	163070	COLD WATER TAP KNOB
27	163195	CONTROL PANEL
28	RTCU700003	WATER TAP
29	RTCU900012	DOUBLE CONE D. 10
30	RTCU900013	NUT D. 10
31	162202	LEFT DOOR
32	162267	FOOT

(R) = - Recommended spare parts



As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.