




Gas Solid Tops


HGT7

HGT2SD7 HGT4S7



Spare Parts






Key No	Part No	Description
3	GACU700130	CONTROL PANEL
14	PACU700548	WORK PLANE
26	GACU700118	CHIMNEY GRILL
30	PACU700525	SUPERIOR CHIMNEY
31	PACU700503	SIDE
32	RTCU700365	COLLECTOR
33	PACU700521	BOTTOM
34	RTCU700308	SAFETY VALVE KNOB
35	RTCU900018	BICONE FOR PIPE Ø 6
36	RTCU900019	NUT FOR PIPE Ø 6
39	RTCU700297	NUT FOR PIPE Ø 10
40	RTCU900012	DOUBLE CONE D.10
44	RTCU700259	TAP
48	RTBF900054	SPY-HOLE
49	PACU700552	FEEDING PIPE FOR BURNER
50	RTCU700288	COOKING PLANE
51	RTCU700366	DISK FOR COOKING PLANE
52	GACU700131	GAS SOLID TOP BURNER
53	RTCU700296	THERMOCOUPLE
54	RTCU900013	NUT
55	RTCU900030	REMOVAL HOOK
56	RTCU700020	PIEZO LIGHTING
57	RTCU900384	LIGHTING CABLE
58	PACU700553	PILOT PIPE
59	RTCU700001	INJECTOR SUPPORT
60	RTCU900005	SUPPORT LOCK NUT
62	RTCP800034	PILOT BODY
63	RTCP800033	SPARK PLUG
65	RTCP800038	THERMOCOUPLE FITTING
66	PACU700556	COMBUSTION CHAMBER
68	RTCU700324	FOOT

Key No	Part No	Description
3	GACU700154	CONTROL PANEL
4	RTCU700375	BURNER CAP 3,5 KW
5	A770000250	GRATE
5	RTCU700341	GRATE
6	PACU700424	SIDE
7	RTCU700382	BURNER 6 KW
8	PACU700572	FRONT BURNER PILOT PIPE
9	PACU700573	BACK BURNER PILOT PIPE
10	GACU700153	CONTROL PANEL
12	GACU700136	FRONT BURNER DISTRIB. PIPE 6 KW
13	GACU700138	TUBO ALIMENT. BRUCIAT. POST. 6 KW
14	PACU700629	WORK PLANE
26	GACU700142	CHIMNEY GRILL
27	RTCU700274	WORK PLANE GRATE
30	PACU700594	SUPERIOR CHIMNEY
31	PACU700503	SIDE
32	RTCU700405	COLLECTOR
32	RTCU700406	COLLECTOR
33	PACU700595	BOTTON
34	RTCU700308	SAFETY VALVE KNOB
35	RTCU900018	BICONE FOR PIPE Ø 6
36	RTCU900019	NUT FOR PIPE Ø 6
37	RTCU700325	INJECTOR SUPPORT
39	RTCU700297	NUT FOR PIPE Ø 10
40	RTCU900012	DOUBLE CONE D.10

Key No	Part No	Description
41	RTCU700259	TAP
43	RTCU700374	THERMOCOUPLE CM. 50
45	RTCU700372	PILOT
46	RTCU700389	PILOT PILOT INJECTOR Ø 0,21
47	RTCU700391	NUT FOR THERMOCOUPLE
48	RTBF900054	SPY-HOLE
49	PACU700552	FEEDING PIPE FOR BURNER
50	RTCU700288	COOKING PLANE
52	GACU700131	GAS SOLID TOP BURNER
53	RTCU700296	THERMOCOUPLE
54	RTCU900013	NUT
55	RTCU900030	REMOVAL HOOK
56	RTCU700020	PIEZO LIGHTING
57	RTCU900384	LIGHTING CABLE
58	PACU700553	PILOT PIPE
59	RTCU700001	INJACTOR SUPPORT
60	RTCU900005	SUPPORT LOCK NUT
62	RTCP800034	PILOT BODY
63	RTCP800033	SPARK PLUG
65	RTCP800038	THERMOCOUPLE FITTING
66	PACU700556	COMBUSTION CHAMBER
68	RTCU700324	FOOT
69	RTCU700028	REDUCTION GRATE
70	RTCU700407	PILOT PLATE



Key No	Part No	Description
3	GACU700157	CONTROL PANEL
4	RTCU700375	BURNER CAP 3,5 KW
5	RTCU700380	BURNER 3,5 KW
6	RTCU700376	BURNER CAP 6 KW
7	RTCU700382	BURNER 6 KW
8	PACU700572	FRONT BURNER PILOT PIPE
9	PACU700573	BACK BURNER PILOT PIPE
11	GACU700138	TUBO ALIMENT. BRUCIAT. POST. 6 KW
12	GACU700136	FRONT BURNER DISTRIB. PIPE 6 KW
13	GACU700137	BACH BURNER DISTRIB. PIPE 3,5 KW
14	PACU700640	WORK PLANE
27	RTCU700274	WORK PLANE GRATE
30	PACU700639	SUPERIOR CHIMNEY
31	PACU700503	SIDE
32	RTCU700408	COLLECTOR
33	PACU700638	BOTTOM
34	RTCU700308	SAFETY VALVE KNOB
35	RTCU900018	BICONE FOR PIPE Ø 6
36	RTCU900019	NUT FOR PIPE Ø 6
37	RTCU700325	INJECTOR SUPPORT
39	RTCU700297	NUT FOR PIPE Ø 10
40	RTCU900012	DOUBLE CONE D.10
41 & 46	RTCU700259	TAP
42	RTCU700373	THERMOCOUPLE CM. 30

Key No	Part No	Description
43	RTCU700374	THERMOCOUPLE CM. 50
45	RTCU700372	PILOT
46	RTCU700389	PILOT PILOT INJECTOR Ø 0,21
47	RTCU700391	NUT FOR THERMOCOUPLE
48	RTBF900054	SPY-HOLE
49	PACU700552	FEEDING PIPE FOR BURNER
50	RTCU700288	COOKING PLANE
52	GACU700131	GAS SOLID TOP BURNER
53	RTCU700296	THERMOCOUPLE
54	RTCU900013	NUT
55	RTCU900030	REMOVAL HOOK
56	RTCU700020	PIEZO LIGHTING
57	RTCU900384	LIGHTING CABLE
58	PACU700553	PILOT PIPE
59	RTCU700001	INJACTOR SUPPORT
60	RTCU900005	SUPPORT LOCK NUT
62	RTCP800034	PILOT BODY
63	RTCP800033	SPARK PLUG
65	RTCP800038	THERMOCOUPLE FITTING
66	PACU700556	COMBUSTION CHAMBER
69	RTCU700028	REDUCTION GRATE
70	RTCU700407	PILOT PLATE



As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.

15.09.2003-Issue-1