









CATALOGO RICAMBI
SPARE PARTS
PIECES DETACHEES
ERSATZTEILE
LISTA DE RECAMBIOS


HSP 5
HSP 50











VASCA - CUVE - TANK
 TANK - CUBA










Fig. 7



31682


230V 50 Hz HP 0,75











A

650138

