



**CATALOGO RICAMBI  
PIECES DETACHEES  
SPARE PARTS  
ERSATZTEILE  
LISTA DE RECAMBIOS**



**Lavastoviglie  
Lavevaisselle  
Dishwashers  
Geschirrspüler  
Lavavajillas**




**VS-X 313  
VS-X 515  
VS-X 313/LP/DOS  
VS-X 515/LP/DOS**




**VS-X 313  
VS-X 313/LP/DOS**

**VS-X 515  
VS-X 515/LP/DOS**

**VS-X 313  
VS-X 515**




Ed.	02/2002
Rev.	
Data	



**VS-X 515  
VS-X 515/LP/DOS**


**VS-X 313  
VS-X 515**




**VS-X 515**  
**VS-X 515/LP/DOS**


**VS-X 313**  
**VS-X 515**

Ed.	02/2002
Rev.	
Data	










Ed.	02/2002
Rev.	
Data	



→12/2001




01/2002→






**→10/2001**



**11/2001→**



Ed.	02/2002
Rev.	
Data	