




**CATALOGO RICAMBI**  
**SPARE PARTS**  
**PIECES DETACHEES**  
**ERSATZTEILE**  
**LISTA DE RECAMBIOS**





**Lavastoviglie**  
**Dishwasher**  
**Lavevaisselle**  
**Geschirrspüler**  
**Lavavajillas**

**AP 53 E**  
**FW 45 E**  
**AP 60 E**  
**FW 50 E**


















Fig. 8








Fig. 8











**38039**


















**650138**

