



| POS. | CODE | PIECES | DESCRIPTION |
|------|-----------|--------|----------------------------|
| 1 | R10201290 | 1 | UPPER DOOR HINGE |
| 2 | R12200630 | 1 | LOWER DOOR HINGE |
| 3 | R12200810 | 1 | FLANGED BUSH |
| 4 | R12200890 | 1 | DOOR HANDLE |
| 5 | R12200900 | 1 | FLANGED HANDLE BRACKET |
| 6 | R12201370 | 1 | RIGHT GLASS FIXING BRACKET |
| 7 | R12202030 | 1 | DOOR |
| 8 | R12202040 | 1 | RIGHT LAMP COVER |
| 9 | R12202050 | 1 | LEFT LAMP COVER |
| 10 | R12403170 | 1 | LEFT GLASS FIXING BRACKET |
| 11 | R12403580 | 1 | INNER DOOR PANEL |
| 12 | R58001920 | 1 | DOOR HANDLE PIN |
| 13 | R58002150 | 1 | HINGE PIN |
| 14 | R58002300 | 1 | DOOR HANDLE ROD |
| 15 | R58002320 | 1 | PUSH ROD |
| 16 | R58002350 | 1 | DOOR HANDLE PRONG PIN |
| 17 | R58002370 | 1 | HANDLE LOCKING BOLT |
| 18 | R58004050 | 1 | NUT FOR UPPER DOOR HINGE |
| 19 | R58004781 | 1 | DOOR HANDLE HOOK |

| POS. | CODE | PIECES | DESCRIPTION |
|------|-----------|--------|------------------------------|
| 20 | R58005050 | 1 | DOOR HANDLE PRONG |
| 21 | R58006370 | 1 | DOOR HANDLE HOOK SCREW |
| 22 | R61090562 | 1 | GRUB SCREW M8x10 |
| 23 | R61620012 | 1 | DOOR HANDLE CATCH SPRING |
| 24 | R61620041 | 1 | DOOR HANDLE BUTTON SPRING |
| 25 | R61620102 | 1 | HANDLE RETURN SPRING |
| 26 | R65270020 | 4 | LIGHT 20W 12V G4 |
| 27 | R65270400 | 4 | LIGHT SOCKET |
| 28 | R67011000 | 1 | HANDLE INSERT BLUE |
| 29 | R69015030 | 1 | DOOR HANDLE ASSEMBLY |
| 30 | R69031220 | 1 | DOOR HANDLE PUSH BUTTON BLUE |
| 31 | R70042510 | 1 | DOOR GASKET |
| 32 | R70042610 | 1 | FRONT GLASS GASKET |
| 33 | R70042710 | 1 | REAR GLASS GASKET |
| 34 | R71200040 | 1 | DOOR GLASS |
| 35 | R71200190 | 1 | DOOR GLASS GOLD/BLUE |

