

TAVOLA / DRAWING 1410

MOD. 7TFEL



ELECTRIC FRY-TOPS TOP S.700S COD.:

338878 LC

338870 L

338882 RC

338874 R



1	401421	MANOPOLA COMP.TERM.FRY-TOP+FORNO EL	KNOB FOR THERMOSTAT
2	4105993	CRUSCOTTO COM.FRY-TOP ELET.400 7/9S	400 GAS FRY TOP FRONT PANEL
3	4127001	CASSETTO RA.GOCCE ASS.FRYTOP S.7/9S	DRIP CATCHER DRAWER
4	4302275	SCARICO FUMO ASS. ASOLE 400 STILE	EXHAUST GRATE
5	431912	PIASTRA EL. 360X570X12 FTLC 740	SMOOTH CHROMIUM PLATE
5	431916	PIASTRA EL.ASS.360X570X12 FTLN 740	SMOOTH PLATE
5	431920	PIASTRA EL. 360X570X12 FTRC 740	SCORED CHROMIUM PLATE
5	431924	PIASTRA EL. 360X570X12 FTRN 740	SCORED PLATE
6	835575	GHIERA PLAST.CHIUSURA MANOP.ELE.13H	PLASTIC COVER FOR KNOB
7	843627	RESISTENZA FRY-TOP 1600W 230V.S.700	HEATING ELEMENT S.700 230V 1600 W FRY-TOP
8	843735	TERMOST.VAR.50-300° FRY 5534062819	WORK THERMOSTAT 50 - 300°
9	843737	TERMOSTATO DI SICUREZZA 5532562808	SAFETY THERMOSTAT
10	843746	COMMUTATORE/INTERRUTTORE 4941015300	MAIN SWITCH/COMMUTATOR
11	843753	STAFFETTA COLLEGAMENTO 0000617078	CONNECTING BRACKET COMM./THERMOSTAT
12	849411	SPIA VERDE V.220	GREEN WARNING LIGHT 220V
13	849417	SPIA ROSSA V.220	RED WARNING LIGHT 220V