





CUCINE TUTTAPIASTRA A GAS

Serie 900

TIPO: 94/04 TCTG, 94/04 TCTGSS, 96/04 TCTGDX, 96/04 TCTGSX, 98/04 TCTG,
94/04 CTGG, 94/04 CTGGSS, 94/04 CTGE, 94/04 CTG, 94/04 CTGSS, 96/04 CTGDX,
96/04 CTGSX, 96/04 CTGGDX, 96/04 CTGGSSX, 96/04 CTGEDX, 96/04 CTGESX,
98/04 CTG, 98/04 CTGG, 98/04 CTGE

Ricambi







Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Parti esterne fuochi e tuttapietra				
10	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Piedino	826490142
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Manopola cucina gas nera	2599200
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Manopola cucina gas Gas Citta	2599220
30	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Griglia smaltata	6A003900
31	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (spartifiamma "C")	2510352
32	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (bicchiere "C")	2510351
35	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (spartifiamma "E") 7kW	2510358
36	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (bicchiere "E")	2510357
40	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bacinella	2547750
50	94,96DX,96SX,98		Magnete	826900011
60			Cerniera inferiore destra superiore sinistra porta	826410020
70			Cerniera inferiore sinistra superiore destra porta	826410010
80			Manopola rubinetto	2599200
80			Manopola rubinetto Gas Citta	2599220
90			Piastra	826901070

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz






Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Parti esterne fuochi e tuttapietra 1/2 modulo				
10	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Piedino	826490142
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Manopola cucina gas nera	2599200
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Manopola cucina gas Gas Citta	2599220
30	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Griglia smaltata	6A003900
31	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bruciatore (spartifiamma "C")	2510352
32	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bruciatore (bicchiere "C")	2510351
35	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (spartifiamma "E") 7kW	2510358
36	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore (bicchiere "E")	2510357
40	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bacinella	2547750
80			Manopola rubinetto	2599200
80			Manopola rubinetto Gas Citta	2599220
110	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS		Accensione piezoelettrica	6A041105
120	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS		Rondella	822160540
130	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS		Cappuccio	826630420
870	94SS,94TSS,94GSS		Piastra	2519670

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz




Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Parti esterne forno gas ed elettrico				
100	94G,96GDX,96GSX,98G,94GSS		Manopola nera per forno e frytop gas	2599202
110	94G,96GDX,96GSX,98G,94GSS		Accensione piezoelettrica	6A041105
120	94G,96GDX,96GSX,98G,94GSS		Rondella	822160540
130	94G,96GDX,96GSX,98G,94GSS		Cappuccio	826630420
140	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS		Portarullini per cerniera	6A035930
150	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS		Cerniera dx	6A035910
160	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS		Cerniera sx	6A035920
170	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS		Suola forno	822420010
180	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS		Griglia	826330020
21	94E,96EDX,96ESX,98E		Guarnizione manopola	2519490
80	94E,96EDX,96ESX,98E		Segnalatori luminosi	6A038506
81	94E,96EDX,96ESX,98E		Gemma bianca	6A039207
190	94E,96EDX,96ESX,98E		Gemma verde	6A038507
200	94E,96EDX,96ESX,98E		Manopola commutatore forno elettrico nera	2599207
210	94E,96EDX,96ESX,98E		Manopola forno elettrico nera	2599214
220	94E,96EDX,96ESX,98E		Resistenza 1500 W	826620041

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz




Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Bruciatori e condutture fuochi aperti				
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Rubinetto	6A011490
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Rubinetto Gas Citta	6A011500
240	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Pilota	2510359
250	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura	2514608
260	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura	2514602
260	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura Gas Citta	2515152
270	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Termocoppia	6A011905
280	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bruciatore (bicchiere "C") 3,5 kW	2510350
290	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Tubo portafiamma	2519000
300	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Raccordo	6A014708
310	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Regolatore d'aria	2519002
320	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bruciatore (bicchiere "E") 7 kW	2510356
330	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura	2514609
390	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Vite	2510610
400	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura	2514603
400	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Conduttura Gas Citta	2515155

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz






Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Ugelli fuochi aperti				
301	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Vite	2510610
302	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Controdado	6A010820
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli IT fuochi aperti bruciatore "C"	2592800
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli IT fuochi aperti bruciatore "E"	2592804
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli DE fuochi aperti bruciatore "C"	2592801
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 80	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 150	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz






Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module:Ugelli fuochi aperti				
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli DE fuochi aperti bruciatore "E"	2592805
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 115	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 200R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli H fuochi aperti bruciatore "C"	2592863
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 150	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli H fuochi aperti bruciatore "E"	2592865
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 175	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 200R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz






Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module:Ugelli fuochi aperti				
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli Gas Citta fuochi aperti bruciatore "C"	2592880
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 265	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 250	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 70	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Kit ugelli Gas Citta fuochi aperti bruciatore "E"	2592882
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 390	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello L 370	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 70	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		By pass	
304	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bicono	6A011470
304	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bicono Gas Citta	6A016300
305	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Dado	6A011475
305	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Dado Gas Citta	6A016200

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz







Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Bruciatori e condutture fuochi aperti				
240	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Pilota	2510359
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 70	6A013110
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 20	6A013101
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Ugello 35	6A013103
242	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Raccordo bicono	6A011608
243	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Regolatore d'aria	6A013104
290	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Tubo portafiamma	2519000

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz





Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module:Rubinetto				
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Rubinetto	6A011490
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Rubinetto Gas Citta	6A011500
270	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Termocoppia	6A011905
710	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Dado	6A011485
710	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Dado Gas Citta	6A016200
720	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bicono	6A011480
720	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bicono Gas Citta	6A016300
730	94SS,94TSS,94GSS		Rubinetto	6A011490
730	94SS,94TSS,94GSS		Rubinetto Gas Citta	6A011500
730	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Rubinetto	6A011500
730	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Rubinetto Gas Citta	6A013600
740	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Raccordo	6A013401
750	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Conduttura	2514750
750	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Conduttura Gas Citta	2515160
750	94SS,94TSS,94GSS		Conduttura	2514755
750	94SS,94TSS,94GSS		Conduttura Gas Citta	2515161
751	94SS,94TSS,94GSS		Dado di fissaggio del bicono	6A011485
751	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Dado Gas Citta	6A016200
752	94SS,94TSS,94GSS		Bicono	6A011480
752	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bicono Gas Citta	6A016300
760	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Conduttura	2514751
760	94SS,94TSS,94GSS		Conduttura	2514756
770	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Dado	6A016110
780	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Bicono	6A016120
480	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS		Termocoppia	6A011904

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGD, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGD, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz







Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Componenti forno a gas				
410	94G,96GDX,96GSX,98G,94GSS		Valvola	8219950
420	94G,96GDX,96GSX,98G,94GSS		Tappo	8219951
430	94G,96GDX,96GSX,98G,94GSS		Raccordo	822450170
440	94G,96GDX,96GSX,98G,94GSS		Accensione piezoelettrica	6A041105
450	94G,96GDX,96GSX,98G,94GSS		Cavo d'accensione	2510698
460	94G,96GDX,96GSX,98G,94GSS		Conduttura	2514615
470	94G,96GDX,96GSX,98G,94GSS		Conduttura	823560060
480	94G,96GDX,96GSX,98G,94GSS		Termocoppia	6A011904
490	94G,96GDX,96GSX,98G,94GSS		Conduttura	823560070
500	94G,96GDX,96GSX,98G,94GSS		Squadretta	2547780
510	94G,96GDX,96GSX,98G,94GSS		Raccordo	6A011707

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz



Parti di ricambio


ID	Tipo	Al	Dal	Voltaggio	Descrizione	Codici
520	94G,96GDX,96GSX,98G,94GSS				Raccordo bicono	6A011608
530	94G,96GDX,96GSX,98G,94GSS				Ugello 19	822140380
530	94G,96GDX,96GSX,98G,94GSS				Ugello 27	6A013107
530	94G,96GDX,96GSX,98G,94GSS				Ugello 36	822140530
530	94G,96GDX,96GSX,98G,94GSS				Ugello 50	6A013108
540	94G,96GDX,96GSX,98G,94GSS				Raccordo	822450040
550	94G,96GDX,96GSX,98G,94GSS				Pilota	826920070
560	94G,96GDX,96GSX,98G,94GSS				Brucciato	2510697
570	94G,96GDX,96GSX,98G,94GSS				Candela	6A013301
580	94G,96GDX,96GSX,98G,94GSS	28/02/2005			Spina elastica	6A011405
590	94G,96GDX,96GSX,98G,94GSS	28/02/2005			Flangia	824710060
600	94G,96GDX,96GSX,98G,94GSS	28/02/2005			Attacco manopola	822160011
610	94G,96GDX,96GSX,98G,94GSS				Bicono	822450050
620	94G,96GDX,96GSX,98G,94GSS				Raccordo	822450010
630	94G,96GDX,96GSX,98G,94GSS				Dado	822180010
640	94G,96GDX,96GSX,98G,94GSS				Rondella	821110840
920	94G,96GDX,96GSX,98G,94GSS		01/03/2005		Attacco manopola	2518650

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG,
 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04
 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/
 04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz



Parti di ricambio



Parti di ricambio


ID	Tipo	Voltaggio	Descrizione	Codici
Module: Componenti forno a gas				
890	94G,96GDX,96GSX,98G,94GSS		Kit ugelli IT DE forno	861310090
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 130	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 245	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 225	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 19	
890	94G,96GDX,96GSX,98G,94GSS		Kit ugelli H forno	2592849
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 245	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 215	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 19	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 36	
890	94G,96GDX,96GSX,98G,94GSS		Kit ugelli Gas Citta forno a gas	2592884
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 225	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 540	
-	94G,96GDX,96GSX,98G,94GSS		Ugello BA 500	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 19	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS		Ugello 50	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz



Parti di ricambio






Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Componenti forno elettrico				
81	94E,96EDX,96ESX,98E		Gemma bianca	6A039207
190	94E,96EDX,96ESX,98E		Gemma verde	6A038507
660	94E,96EDX,96ESX,98E		Commutatore	6A046750
670	94E,96EDX,96ESX,98E		Termostato	826630123
680	94E,96EDX,96ESX,98E		Termostato sicurezza	826630130
690	94E,96EDX,96ESX,98E		Commutatore	6A046001
220	94E,96EDX,96ESX,98E		Resistenza 1500 W	826620041
910	94E,96EDX,96ESX,98E		Contattore	6A047031

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz

Parti di ricambio




Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module: Pilota e bruciatore tuttapietra				
480			Termocoppia	6A011904
790			Dado	6A017000
800			Bicono	6A016900
810			Ugello 27.2	6A013230
810			Ugello 16.2	6A013240
810			Ugello 38.1.2	2510332
810			Ugello 45.2	2510716
820			Candela di accensione	6A013302
830			Pilota	6A013220
840	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Bruciatore tuttapietra	2510069
850	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Controdado	6A010820
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Kit ugelli IT bruciatore	2592810
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 270R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		By pass	
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Kit ugelli DE bruciatore	2592811
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 155R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 280R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDGX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDGX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz







Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module:Pilota e bruciatore tuttapietra				
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Kit ugelli H bruciatore	2592857
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 235R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 270R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 38.1.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		By pass	
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Kit ugelli Gas Citta bruciatore	2592885
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello L 560	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		Ugello 45.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E		By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz





Parti di ricambio

ID	Tipo	Voltaggio	Descrizione	Codici
Module:Pilota e bruciatore tuttapietra 1/2 modulo				
480			Termocoppia	6A011904
790			Dado	6A017000
800			Bicono	6A016900
810			Ugello 27.2	6A013230
810			Ugello 16.2	6A013240
810			Ugello 38.1.2	2510332
810			Ugello 45.2	2510716
820			Candela di accensione	6A013302
830			Pilota	6A013220
880	94SS,94TSS,94GSS		Bruciatore tuttapietra	2519420
850	94SS,94TSS,94GSS		Controdado	6A010820
860	94SS,94TSS,94GSS		Kit ugelli IT bruciatore	2592875
-	94SS,94TSS,94GSS		Ugello L 135	
-	94SS,94TSS,94GSS		Ugello L 200	
-	94SS,94TSS,94GSS		Ugello L 210	
-	94SS,94TSS,94GSS		Ugello 16.2	
-	94SS,94TSS,94GSS		Ugello 27.2	
-	94SS,94TSS,94GSS		By pass	
860	94SS,94TSS,94GSS		Kit ugelli DE bruciatore	2592876
-	94SS,94TSS,94GSS		Ugello L 115	
-	94SS,94TSS,94GSS		Ugello L 200	
-	94SS,94TSS,94GSS		Ugello L 220	
-	94SS,94TSS,94GSS		Ugello 16.2	
-	94SS,94TSS,94GSS		Ugello 27.2	
-	94SS,94TSS,94GSS		By pass	
860	94SS,94TSS,94GSS		Kit ugelli H bruciatore	2592877
-	94SS,94TSS,94GSS		Ugello L 135	
-	94SS,94TSS,94GSS		Ugello L 190	
-	94SS,94TSS,94GSS		Ugello L 215	
-	94SS,94TSS,94GSS		Ugello 16.2	
-	94SS,94TSS,94GSS		Ugello 27.2	
-	94SS,94TSS,94GSS		Ugello 38.1.2	
-	94SS,94TSS,94GSS		By pass	
860	94SS,94TSS,94GSS		Kit ugelli Gas Citta bruciatore	2592888
-	94SS,94TSS,94GSS		Ugello L 135	
-	94SS,94TSS,94GSS		Ugello L 200	
-	94SS,94TSS,94GSS		By pass	
-	94SS,94TSS,94GSS		Ugello 16.2	
-	94SS,94TSS,94GSS		Ugello 27.2	
-	94SS,94TSS,94GSS		Ugello 45.2	
-	94SS,94TSS,94GSS		Ugello L 380	
-	94SS,94TSS,94GSS		Ugello L 355	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDGX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDGX, 96SX=96/04 CTGSX, 96GDGX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz

