



SOLO PER CASSETTI  
 DRAWERS ONLY  
 NUR FUER SCHBLADEN  
 SEULEMENTO POUR TIROIRS  
 SOLO GAVETAS





# Modello Typ Model Modele Modelo

		EM1A EM1A/X EM1A/A	EM1A/2 EM1A/2X EM1A/2A	EM1B EM1B/X EM1B/A	EM1B/2 EM1B/2X EM1B/2A	EM1B/4 EM1B/4X EM1B/4A	EM1C EM1C/X EM1C/A	EM1C/2 EM1C/2X EM1C/2A	EM1C/4 EM1C/4X EM1C/4A	EM1C/6 EM1C/6X EM1C/6A
Porte Türe Doors Portes Portas Gabetas	SX	1	1	2	2	1	3	3	2	1
	DX	1	...	1	...	...	1	...	...	...





# Modello Typ Model Modelle Modelo

		<b>EM1A</b> <b>EM1A/X</b> <b>EM1A/A</b>	<b>EM1A/2</b> <b>EM1A/2X</b> <b>EM1A/2A</b>	<b>EM1B</b> <b>EM1B/X</b> <b>EM1B/A</b>	<b>EM1B/2</b> <b>EM1B/2X</b> <b>EM1B/2A</b>	<b>EM1B/4</b> <b>EM1B/4X</b> <b>EM1B/4A</b>	<b>EM1C</b> <b>EM1C/X</b> <b>EM1C/A</b>	<b>EM1C/2</b> <b>EM1C/2X</b> <b>EM1C/2A</b>	<b>EM1C/4</b> <b>EM1C/4X</b> <b>EM1C/4A</b>	<b>EM1C/6</b> <b>EM1C/6X</b> <b>EM1C/6A</b>
<b>Num. Cassetti</b> <b>Schubläd</b> <b>Drawers</b> <b>Tiroirs</b> <b>Gabetas</b>	<b>1/2</b>	-	<b>2</b>	-	<b>2</b>	<b>4</b>	-	<b>2</b>	<b>4</b>	<b>6</b>

