



SOLO PER CASSETTI  
 DRAWERS ONLY  
 NUR FUER SCHBLADEN  
 SEULEMENTO POUR TIROIRS  
 SOLO GAVETAS



# Modello Typ Model Modele Modelo

|   |    |                             |                                 |                             |                                 |                                 |                             |                                 |                                 |                                 |
|---|----|-----------------------------|---------------------------------|-----------------------------|---------------------------------|---------------------------------|-----------------------------|---------------------------------|---------------------------------|---------------------------------|
|   |    | EXM1A<br>EXM1A/X<br>EXM1A/A | EXM1A/2<br>EXM1A/2X<br>EXM1A/2A | EXM1B<br>EXM1B/X<br>EXM1B/A | EXM1B/2<br>EXM1B/2X<br>EXM1B/2A | EXM1B/4<br>EXM1B/4X<br>EXM1B/4A | EXM1C<br>EXM1C/X<br>EXM1C/A | EXM1C/2<br>EXM1C/2X<br>EXM1C/2A | EXM1C/4<br>EXM1C/4X<br>EXM1C/4A | EXM1C/6<br>EXM1C/6X<br>EXM1C/6A |
| Porte<br>Türe<br>Doors<br>Portes<br>Portas<br>Gabetas | SX | 1                           | 1                               | 2                           | 2                               | 1                               | 3                           | 3                               | 2                               | 1                               |
|   | DX | 1                           | ...                             | 1                           | ...                             | ...                             | 1                           | ...                             | ...                             | ...                             |



# Modello Typ Model Modelle Modelo

|  |     |                             |                                 |                             |                                 |                                 |                             |                                 |                                 |                                 |
|--|-----|-----------------------------|---------------------------------|-----------------------------|---------------------------------|---------------------------------|-----------------------------|---------------------------------|---------------------------------|---------------------------------|
|  |     | EXM1A<br>EXM1A/X<br>EXM1A/A | EXM1A/2<br>EXM1A/2X<br>EXM1A/2A | EXM1B<br>EXM1B/X<br>EXM1B/A | EXM1B/2<br>EXM1B/2X<br>EXM1B/2A | EXM1B/4<br>EXM1B/4X<br>EXM1B/4A | EXM1C<br>EXM1C/X<br>EXM1C/A | EXM1C/2<br>EXM1C/2X<br>EXM1C/2A | EXM1C/4<br>EXM1C/4X<br>EXM1C/4A | EXM1C/6<br>EXM1C/6X<br>EXM1C/6A |
| Num. Cassetti<br>Schubläd<br>Drawers<br>Tiroirs<br>Gabetas | 1/2 | -                           | 2                               | -                           | 2                               | 4                               | -                           | 2                               | 4                               | 6                               |

