

TAB-* - DISEGNI/DIAGRAMS - D

13

12

11 - 2 Pz.

10

9

8

TAB-B

7




Part.A

6

5

4

15



14




TAB-E


1

2

3

TAB-A





CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT
Aggiornato al/Updated to 27/11/17

Artic./Item	Descrizione/Description			Modello/Model
613013	CUCINA GAS "TUTTA PIASTRA" CON FORNO GAS GN2/1 GAS SOLID TOP RANGE WITH GN2/1 GAS OVEN			PPF70GG7
Cons./Recom.	Pos./Posit.	Ricambio/Replacement		Prezzo/Price List
*	00118000	RC00118000	TERMOCOPPIA M9X1 L600	TERMOCOUPLE 15,56
*	00123000	RC00123000	CAVO PER CANDELETTA	WIRE FOR SPARK PLUG 9,27
	00984000	RC00984000	COPERCHIO GHISA PIASTRA CENTRALE	CAST IRON COVER FOR CENTRAL PLATE 42,59
	01051000	RC01051000	CAMINO 700 L7	FLUE 700 L7 118,28
*	01072000	RC01072000	CAVETTO PER ACCENDITORE FORNO L7	OVEN LIGHTER CABLE L7 22,29
	01160000	RC01160000	COPPIA PIASTRA IN GHISA	HOT PLATE ASSEMBLY 612,68
	01161000	RC01161000	BRUCIATORE CIRCOLARE PIASTRA	BURNER 40,15
	01887000	RC01887000	MANOPOLA GAS NERA	GAS BLACK KNOB 8,15
	01900000	RC01900000	ANELLO CAPPuccio PIEZO	PIEZO IGNITER NIPPLE RING 8,99
	02074000	RC02074000	MANOPOLA GAS GRIGIA	GREY KNOB 8,79
*	05001400	RC05001400	RUBINETTO GAS	GAS COCK 79,66
	501	RC01134000	BRUCIATORE FORNO	OVEN BURNER 41,70
	504	RC01136000	FONDO FORNO ESTRAIBILE SMALTATO	EXTRACTABLE OVEN BOTTOM 20,97
	505	RC01069000	COPERCHIETTO D'ISPEZIONE FORNO L7	COVER 21,63
	506	RC01826000	GUARNIZIONE TESSILE PER FORNO GN	TEXTILE GASKET FOR OVEN 52,43
	507	RC01345000	PORTA FORNO L7 CON MANIGLIA ANTRACITE	OVEN DOOR ANTHRACITE L7 262,05
	507	RC02028000	PORTA FORNO GN2/1 TECNO70	DOOR W/HANDLE 277,87
	508	RC02082000	MANIGLIA FORNO	OVEN HANDLE 55,54
	509	RC01064000	ZOCCOLO FORNO L7	OVEN SOCLE L7 46,45
	510	RC01068000	CERNIERA SX PORTA FORNO GN C/P.RULLINO	LEFT HINGE 37,51
*	511	RC00128000	ACCENDITORE PIEZO CON DADO	PIEZO IGNITER 16,99
*	512	RC01685000	CAPPuccio IN GOMMA PER PIEZO	GUMMY CAP FOR PIEZO IGNITER 9,71
	513a	RC02058000	MANOPOLA FORNO GAS NERA	BLACK KNOB 8,15

CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT

Aggiornato al/Updated to 27/11/17

Artic./Item	Descrizione/Description		Modello/Model
613013	CUCINA GAS "TUTTA PIASTRA" CON FORNO GAS GN2/1 GAS SOLID TOP RANGE WITH GN2/1 GAS OVEN		PPF70GG7
Cons./Recom.	Pos./Posit.	Ricambio/Replacement	Prezzo/Price List
	513b	RC02070000 MANOPOLA FORNO GAS GRIGIA	GREY KNOB 8,79
	515	RC01133000 RUBINETTO FORNO GAS	OVEN THERMOSTATIC GAS COCK 167,04
	516	RC00602000 PIEDE 1"3/4 INOX	FOOT 36,41
	517	RC01067000 CERNIERA DX PORTA FORNO GN C/P.RULLINO	RIGHT HINGE 37,51
	518	RC01056000 PIOLINO SUPP.GRIGLIA FORNO EL.STATICO	HOOK 6,51
	519	RC01057000 SUPPORTO GRIGLIA FORNO EL.STATICO	OVEN TRAY RUNNER 18,65
	520	RC00414000 PORTAUGELLO	NOZZLE HOLDER 9,50
*	522	RC01483000 TERMOCOPPIA L=1500 M8X1L11 A1	THERMOCOUPLE L=1500 M8X1L11 A1 17,99
*	524	RC00119000 PILOTA ACCENDITORE 3 VIE	PILOT IGNITER 23,17
*	526	RC00120000 CANDELETTA D'ACCENSIONE	SPARK PLUG 13,47